



## CRUX Rip-Out Diaphragms

In certain circumstances Crux Rip-Out Diaphragms may be specified. These buoyancy diaphragms have an integral cutting tool attached which pierces the diaphragm when activated by means of wire rope rigging from the surface.



The function of Rip-Out Diaphragms is to accentuate the flooding of previously sealed jacket members or buoyancy tanks, by pulling a cruciform cutter through the diaphragm.

